



**WINDAGE TRAY, BIG BLOCK CHEVROLET
P/N 23030
INSTALLATION INSTRUCTIONS**

1. Place the tray on the main cap studs with the crankshaft.
2. Secure the studs using washers and nuts. (We recommend the use of thread sealer such as Loctite or Nut-Loc.)
3. When using this tray with oil pump mounted directly to the main cap, no trimming is required.
4. When using this tray with a Moroso Oil Pump Extension, trim Windage Tray to provide adequate clearance around extension block. 23030INST

***For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time***

MOROSO PERFORMANCE PRODUCTS, INC

80 CARTER DR • GUILFORD, CT 06437

Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com