



**OIL PUMP BLOCK-OFF PLATE  
P/N 23790  
INSTALLATION INSTRUCTIONS**

This product was designed to be used exclusively with a dry sump or single-stage oiling system. The Moroso #23790 Oil Pump Block-off Plate may be installed on either Big or Small Block Chevrolets without modification.

First, remove stock oil pump and intermediate drive shaft. After thoroughly cleaning all surfaces, place the block-off plate on the oil pump mounting boss. After seating plate onto locator pins, spread a few drops of oil onto the threads of the bolt and under the bolt's head.

Tighten the mounting bolt to approximately 50-55 ft./lbs. and the installation is complete. 23790INST

***For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542. 458-0546 8:30am – 5:00pm Eastern Time***

*MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437  
Phone: (203) 453-6571 • Fax: (203) 453-6906*

**Visit Us At [www.moroso.com](http://www.moroso.com)**