



**FLEX PLATE BOLTS
P/N 38760
INSTALLATION INSTRUCTIONS**

Fits: Small Block, Big Block, and 90° Chevy V6 Engines
Contains: (6) 7/16"-20 x 11/16" Grade 8 Bolts with Washers

1. Prior to installing the flywheel, it is highly recommended that the threads in the crankshaft flywheel flange be chased (cleaned) with a 7/16"-20 tap.
2. Also prior to mounting, check for a snug fit between the I.D. of the flywheel and the crankshaft flywheel register.
3. Apply oil or suitable lubricant to the threads and install all bolts by hand. Torque all bolts to 60 ft./lbs. in three stages. Begin at 20 ft./lbs., then 40 ft./lbs., and finally 60 ft./lbs. Always torque in a "star pattern" – begin with one bolt followed by the opposite bolt (180° away). Then torque another bolt and its opposite, ending with the last pair.

REV. B

111513

38760INST

***For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time***

MOROSO PERFORMANCE PRODUCTS, INC

80 CARTER DR • GUILFORD, CT 06437

Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com