



**FORD C6 TRANSMISSION PAN
P/N 42060**

PARTS LIST:

- 1 Transmission Pan**
- 17 Serrated Flange Hex Bolts**

IMPORTANT INSTALLATION NOTE:

**This Transmission Pan must be used with any of the following filters:
Ford P/N D3TZ7A098B
Fram P/N FT1055**

- 1. Drain fluid and remove old pan. Clean any old gasket material from the pan-mounting surface on the transmission. Remove the old filter and replace with a new one listed above.**
- 2. Place a new gasket on the pan rail, tighten the pan with supplied Serrated Flange Hex Bolts. Torque to 10 ft-lbs. (NOTE: Moroso does not recommend using any type of sealer on the gasket. Small pieces may dislodge and clog the transmission or transbrake internals resulting in failure. Moroso also recommends using our P/N 93108 Perm-Align Transmission Gasket.)**
- 3. Check that the drain plugs are tight. Fill the trans with fresh fluid to the proper level on the dipstick.**

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

*MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906*