



**INSTALLATION INSTRUCTIONS
-12AN REMOTE ADAPTER KIT SMALL BLOCK MOPAR
273-360 CUBIC INCH ENGINES**

P/N 63514

PARTS LIST

- (3) 3/8-16 X 7/8" STAINLESS SHCS (4) 3/8-16 x 3 1/2" STAINLESS SHCS
(1) GASKET, SBM (1) REMOTE WATER PUMP ADAPTER**

INSTALLATION

This remote –12AN Adapter Kit is made for our customers utilizing a remote water pump and an auxiliary radiator fan. The adapter is designed to fit in the stock water pump ort location on the engine.

- 1. Disconnect and remove the terminal from the negative battery terminal post.**
- 2. Drain the fluid from the cooling system.**
- 3. Remove the existing water pump.**
- 4. Check and clean any old sealing material that may prevent the gaskets from sealing on the block.**

NOTE: Lubricate the screw threads with oil prior to installation.

- 5. Coat both sides of the supplied gasket with a high quality gasket sealer to prevent leaks.**
- 6. Install the new fasteners and torque to 11 ft-lbs and final torque to 20 ft-lbs.**
- 7. Plumb the Remote Water Pump to the radiator and engine block with –12AN fittings (not included).**
- 8. Refill the coolant system and service the coolant system per manufacturers service manual.**
- 9. Re-connect the negative battery terminal to its post.**

Thank you for purchasing Moroso Performance Products.

***For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time***

**MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906**

**REV.A
082712**

Visit Us At www.moroso.com

63514INST