



**INSTALLATION INSTRUCTIONS**  
**-12AN REMOTE ADAPTER KIT SMALL BLOCK FORD**  
**(FITS IN PLACE OF STANDARD ROTATION WATER PUMPS)**

**P/N 63515**

**PARTS LIST**

- |  |                                     |
|--|-------------------------------------|
| <b>(2) 5/16-18 X 1" Stainless SHCS</b>   | <b>(1) Gasket, SBF</b>              |
| <b>(4) 5/16-18 X 3" Stainless SHCS</b>   | <b>(1) -12AN Remote W/P Adapter</b> |
| <b>(3) 5/16-18 X 7/8" Stainless BHCS</b> |                                     |

**INSTALLATION**

This remote -12AN Adapter Kit is made for our customers utilizing a remote water pump and an auxiliary radiator fan. The adapter is designed to fit in the stock water pump port location on the engine.

- 1. Disconnect and remove the terminal from the negative battery terminal post.**
- 2. Drain the fluid from the cooling system.**
- 3. Remove the existing water pump.**
- 4. Check and clean any old sealing material that may prevent the gaskets from sealing on the block.**

**NOTE: Lubricate the screw threads with oil prior to installation.**

- 5. Coat both sides of the supplied gasket with a high quality gasket sealer to prevent leaks.**
- 6. Install the new fasteners and torque to 11 ft-lbs and final torque to 15 ft-lbs.**
- 7. Plumb the Remote Water Pump to the radiator and engine block with -12AN fittings (not included).**
- 8. Refill the coolant system and service the coolant system per manufacturers service manual.**
- 9. Re-connect the negative battery terminal to its post.**

**Thank you for purchasing Moroso Performance Products.**

*For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am - 5:00pm Eastern Time*

*MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437  
Phone: (203) 453-6571 • Fax: (203) 453-6906*

REV.B  
112812

**Visit Us At [www.moroso.com](http://www.moroso.com)**

63515INST