



**INSTALLATION INSTRUCTIONS  
-12AN REMOTE ADAPTER KIT BIG BLOCK FORD**

**P/N 63516**

**PARTS LIST**

- (3) 5/16-18 x 7/8" STAINLESS BHCS (1) GASKET BBF  
(2) 5/16-18 X 1" STAINLESS SHCS (6) 5/16-18 X 3 1/4" STAINLESS SHCS  
(1) -12AN REMOTE W/P ADAPTER

**INSTALLATION**

This remote -12AN Adapter Kit is made for our customers utilizing a remote water pump and an auxiliary radiator fan. The adapter is designed to fit in the stock water pump port location on the engine.

10. Disconnect and remove the terminal from the negative battery terminal post.
11. Drain the fluid from the cooling system.
12. Remove the existing water pump.
13. Check and clean any old sealing material that may prevent the gaskets from sealing on the block.
14. Coat both sides of the supplied gasket with a high quality gasket sealer to prevent leaks.

**NOTE: Lubricate the screw threads with oil prior to installation.**

15. Install the new fasteners and torque to 11 ft-lbs and final torque to 15 ft-lbs.
16. Plumb the Remote Water Pump to the radiator and engine block with -12AN fittings (not included).
17. Refill the coolant system and service the coolant system per manufacturers service manual.
18. Re-connect the negative battery terminal to its post.

**Thank you for purchasing Moroso Performance Products.**

*For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am - 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437  
Phone: (203) 453-6571 • Fax: (203) 453-6906

REV.A  
082712

**Visit Us At [www.moroso.com](http://www.moroso.com)**

63516INST