



INSTALLATION INSTRUCTIONS

P/N 65951 - CARBURETOR AIR PAN KIT - DUAL 4500 CARBS

TO INSTALL AIR PAN: First measure opening in scoop adding 3" to the front to rear dimension for the foam seal. Drill 1/8" and pop rivet the two pan halves together at this dimension. Install carb flanges on carburetors and lay the riveted pan on top. Place hood and scoop on car, centering pan in scoop opening. Remove hood and scoop and mark flange location on pan. Cut out an 8" diameter hole, centrally placed to each flange location. Using supplied rivets, drill and mount carb flanges to pan. Lay the foam strip inside the outer lip and measure the length needed. Cut the foam to length and glue to pan assembly with weather stripping cement.

PARTS LIST

- 2 ALUMINUM PANS
- 2 4500 CARB FLANGES
- 20 1/8 X 1/4 POP RIVETS
- 1 FLAME RETARDANT FOAM 1 1/2 X 4 X 60

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906