



**PART#65960  
CARBURETOR AIR PAN KIT**

**PARTS LIST**

- 1 ALUMINUM PAN WITH OFF-CENTER 5 1/8" HOLE**
- 1 ALUMINUM PAN WITH NO HOLE**
- 1 FLAME RETARDANT FOAM STRIP, 1 1/2" X 4" X 60"**
- 4 ALUMINUM POP RIVETS**

**FOR SINGLE 5 1/8" NECK CARBURETOR APPLICATIONS ONLY**

**To install air pan, first place pan with 5 1/8" hole over carburetor and check alignment with hood scoop opening. This pan can be rotated to put the blank pan either in front of or behind the carburetor. Place the blank pan in position, align with scoop opening, and mark over lap with other pan. Using this mark as a guide, drill and pop rivet the pans together. Lay the foam strip inside the outer lip and measure the length needed. Cut the foam to length and glue to pan assembly with weather stripping cement.**

***For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time***

**MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437  
Phone: (203) 453-6571 • Fax: (203) 453-6906**

Rev.B  
011011

**Visit Us At [www.moroso.com](http://www.moroso.com)**

65960INST