



INSTALLATION INSTRUCTIONS

BRAKE BOOSTER COVER
P/N: 74256, MUSTANG 15 and up

This kit has been specifically designed to fit the 2015 Ford Mustang brake reservoir cover. It includes all the necessary hardware to secure it in place. The cover supplied is raw aluminum. It can be polished, anodized or powder coated.

PARTS LIST			
DESCRIPTION	QTY	DESCRIPTION	QTY
COVER	1	HOOK DOTS	3
		LOOP DOTS	3



Figure 1

1. Protect cover from being scratched and rest it on a work surface.
2. Clean inside of cover with rubbing alcohol.



Figure 2



Figure 3

INSTALLING COVER

1. Degrease and clean top of master cylinder taking care to not contaminate the fluid.
2. Peel and stick three hook dots as shown in Figure 2.
3. Without peeling the backing, align and mate the loop dots to the hook dots shown in Figure 2.
4. Peel the backing off of the mated loop dots.

INSTALLING COVER (cont'd)

5. Remove brake reservoir cap and carefully install cover.
6. Press and hold the cover in place for 30 seconds.
7. Install cap.
8. Be sure that the wires for the brake fluid sensor are safely routed away from the cover so that they do not become chafed or cut.
9. In some instances where your vehicle is equipped with a factory line lock you may have to gently move the brake lines away from the brake booster to provide additional clearance.

CAUTION: NEVER REMOVE COVER WHEN THE ENGINE IS HOT TO PREVENT THE POSSIBILITY OF REMOVING THE DOTS.

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, (203) 458-0546 8:30am-5:00pm EST**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com