



Panhard Bar Brace, Street/Strip

Part# C2137

Installation instructions

To aid the installation of this suspension product, mark the rear shock absorber Relative to the protective skirt. With the vehicle at ride height.(curb height).

Place the transmission in neutral, and hoist the vehicle into position. While the vehicle is in the air support the rear axle and raise until the marks made on the shock tubes line up.

Remove factory Panhard Bar Brace.

1. Position new Panhard Bar Brace and starting on the passenger's side, slide a bolt through the cross tube, hand tighten.
2. Insert the two driver's side bolts and torque to 46lb/ft. (Ford Motor Company Workshop Manual)
3. Torque the passenger's side tube bolt to 85lb/ft.
4. Re-install wheels.
5. Lower vehicle and road test.

*For Technical Assistance, call Competition Engineering's Tech Line at
(203) 458-0542, (203) 458 0546 8:30am-5:00pm Eastern Time*

COMPETITION ENGINEERING

80 Carter Drive • Guilford, CT 06437

Phone: (203) 453-5200 • Fax: (203) 453-6906

Rev.A
042408

Visit Us At www.competitionengineering.com

C2137INST