



Panhard Bar Street/Strip

Part# C2139

Installation instructions

To aid the installation of this suspension product, mark the rear shock absorber relative to the protective skirt. With the vehicle at ride height.(curb height).

Place the transmission in neutral, and hoist the vehicle into position. While the vehicle is in the air support the rear axle and raise until the marks made on the shock tubes line up.

Remove factory Panhard Bar (it may necessary to pry it out).

1. Position new Panhard Bar in vehicle with the grease fittings pointing down.
2. Re-install the factory retaining bolts and torque to 129lb/ft.(Ford Motor Company Workshop Manual)
3. Grease each fitting and re-install wheels.
4. Lower vehicle and road test.

*For Technical Assistance, call Competition Engineering's Tech Line at
(203) 458-0542,(203) 458 0546 8:30am-5:00pm Eastern Time*

COMPETITION ENGINEERING

80 Carter Drive • Guilford, CT 06437

Phone: (203) 453-5200 • Fax: (203) 453-6906