

P/N 23705

Remove the factory oil filter adapter from engine. Assemble the components as shown in the illustration below. Make certain to use #10AN fittings and O-rings to plumb your oil cooler. This adapter has no bypass valve for the oil filter.

