



P/N 63909
VACUUM PUMP MOUNTING PLATE,
BIG BLOCK FORD MOTOR

PARTS LIST

1 VACUUM PUMP MOUNTING BRACKET	3 3/8" X 1" BOLT
3 ALUMINUM SPACERS 2-3/8"	6 13/32" I.D. WASHERS
3 ALUMINUM SPACERS 7/8"	3 3/8 X 3-1/4" BOLTS
3 ALUMINUM SPACERS 3-3/8"	3 3/8" X 1-3/4" BOLTS
3 ALUMINUM SPACERS 1-7/8"	3 3/8" X 4-1/4" BOLTS
3 3/8" X 2-3/4" BOLTS	

NOTE: This mount is engineered to mount Moroso vacuum pumps part #s 22640 & 22641 to either cylinder head of a BB Ford motor.

NOTE: This kit can be used with either the stock length crank snout or the shorter BOSS snout found on some racing cranks.

INSTALLATION

1. After confirming which hardware your engine requires you to use. Place bolts through the mounting bracket and install a corresponding spacer on each.
2. Install the Vacuum Pump Mounting Bracket.

Hardware combinations for various installations:

- a. Stock type crank with driver's side v/pump use 4-1/4" Bolts and 3-3/8" Spacers.
- b. Stock crank with passenger's side v/pump use 3-1/4" Bolts and 2-3/8" Spacers.
- c. Boss crank with driver's side v/pump use 2-3/4" Bolts and 1-7/8" Spacers.
- d. Boss crank with passenger's side v/pump use 1-3/4" Bolts and 7/8" Spacers.

NOTES :

- FOR ENGINES USING A DAMPER WITH BBC GEOMETRY, USE MOROSO PART# 63849 DRIVE MANDREL.
- ENGINES USING HARMONIC DAMPERS WITH OEM GEOMETRY USE MOROSO ADAPTER RING PART# 63847 TO MOUNT MANDREL PART# 63853.
- WHEN INSTALLED ON THE PASSENGER SIDE HEAD, THE KIT WOULD HAVE THE MIRROR IMAGE OF FIG 1.



FIG 1 (Bracket mounted on driver's side head)

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev. B
011111

Visit Us At www.moroso.com

63909 INST