

BOLT-ON VALVE COVER FITTING P/N 68842

PARTS LIST

FILL CAP FILL CAP O-RING THREADED FITTING LOCKING PLATE 10-24 SCREWS (4) O-RING FOR FITTING

INSTALLATION

Select a location for the fitting on a flat surface. Use the steel locking plate as a template for laying out the locations for the holes. Use a 13/64" drill for the screws and a 1.250" hole saw for the center opening. Once the holes are made, de-burr and clean them. Assemble the fitting as shown in the illustration below. Once the fitting has been secured, bend the tabs of the locking plate up and over the bolt heads.



For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC 80 CARTER DR • GUILFORD, CT 06437 Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev. A 110211 Visit Us At www.moroso.com

68842INST