

Quick Disconnect Starter Harness PART #74245

DESIGNED TO FIT MOST TILTON STYLE STARTER MOTORS

INSTALLATION

- 1. Disconnect the positive battery cable from the battery.
- Disconnect the starter wires from the solenoid, carefully noting the color of each wire and the terminal it was attached to.
- Pull the starter wires out of the way and clip the Moroso Harness over the solenoid. Attach the two (2) harness wires to the starter solenoid.
- 4. Splice the wires from the harness to the original starter wires on the car. (We recommend soldering the wires or using an appropriately sized butt connector). Be certain the wires eventually go to the same terminal they came from in step No. 2.
- 5. Reconnect the battery cable.

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC 80 CARTER DR • GUILFORD, CT 06437 Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev.C 020513 Visit Us At www.moroso.com

74245INST



Quick Disconnect Starter Harness PART #74245

DESIGNED TO FIT MOST TILTON STYLE STARTER MOTORS

INSTALLATION

- 1. Disconnect the positive battery cable from the battery.
- 2. Disconnect the starter wires from the solenoid, carefully noting the color of each wire and the terminal it was attached to.
- Pull the starter wires out of the way and clip the Moroso Harness over the solenoid. Attach the two (2) harness wires to the starter solenoid.
- 4. Splice the wires from the harness to the original starter wires on the car. (We recommend soldering the wires or using an appropriately sized butt connector). Be certain the wires eventually go to the same terminal they came from in step No. 2.
- 5. Reconnect the battery cable.

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC 80 CARTER DR • GUILFORD, CT 06437 Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev. C 020513