

DOOR LIMIT STRAP KIT PART#C4931

PARTS LIST

(2) DOOR STRAPS

(2) BRACKETS

(4) CAP SCREWS

(4) NYLOC NUTS

INSTALLATION INSTRUCTIONS

- 1. First determine the mounting location of the Strap **NOTE**: The Strap will be mounted towards the front of the door on the inner door panel.(facing the driver).
- 2. The mounting bracket for the strap is actually an integral part of the strap itself.
- 3. Drill (2) holes in the inner door panel using the Strap Bracket for a template.
- 4. After ensuring that the door will open sufficiently tack weld the supplied weld-on Bracket to the door X-brace.
- 5. Clip the strap in the bracket and adjust the strap to lengthen or shorten it until the door is able to open the desired amount.
- 6. When you are satisfied with the placement of the Strap Bracket and the weld-on Bracket weld the Bracket to the X-Brace.

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 8:30am – 5:00pm Eastern Time

COMPETITION ENGINEERING 80 Carter Drive, Guilford, CT 06437

Phone: (203) 453-5200 • Fax: (203) 453-6906