

P/N 23815 INSTALLATION INSTRUCTIONS

INSTALLATION INSTRUCTIONS

Always use the proper tools and equipment, wear safety glases and disconnect the battery when working on your vehicle.

To install your new Block-Off Plate, remove the oil filter from the engine and clean the area where the filter attaches. Make sure the old oil filter o-ring is not stuck to engine block. Apply a small amount of oil to the Moroso Block-Off Plate to lubricate the o-ring and hand-tighten the Block-Off Plate to the engine block. Tighten an additional 1/2 turn with a wrench.

Connect the -10 AN fitting to the remote oil filter mount. When all work is completed, check the oil level, run vehicle and check for leaks

REV. B 110811 23815INST

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am - 5:00pm Eastern Time MOROSO PERFORMANCE PRODUCTS, INC 80 CARTER DR • GUILFORD, CT 06437 Phone: (203) 453-6571 • Fax: (203) 453-6906