



INSTALLATION INSTRUCTIONS

P/N 39020 and 39021 HOOD PIN SETS

NOTE: We highly recommend at least six hood pins per hood, when the hood pins are the only means of attachment.

INSTALLATION

For each pin (refer to diagram for component location).

1. Determine hood pin location and mount pin.
2. Drill 17/32 hole in hood.
3. Place scuff plate over pin and drill 4 mounting holes, use 3 fasteners to attach.
4. Thread lanyard through fourth hole and crimp rivet eyelet.
5. Adjust pin height to desired location.

PARTS LIST #39020

- | | |
|---|------------------------|
| 4 | 1/2-20 JAM NUT |
| 2 | HOOD PIN 1/2-20 CHROME |
| 2 | SCUFF PLATE |
| 2 | HOOD PIN CLIP (CHROME) |
| 2 | LANYARDS |
| 2 | RIVER EYELET |

PARTS LIST #39021

- | | |
|---|-------------------------|
| 4 | 7/16-20 RH JAM NUT |
| 2 | HOOD PIN 7/17-20 CHROME |
| 2 | SCUFF PLATE |
| 2 | HOOD PIN CLIP (CHROME) |
| 2 | LANYARDS |
| 2 | RIVER EYELET |



**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am - 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906