



**INSTALLATION INSTRUCTIONS
-12AN REMOTE ADAPTER KIT SMALL BLOCK CHEVY
P/N 63512**

PARTS LIST

- | | |
|---|-------------------------------------|
| (4) 3/8-16 X 7/8" STAINLESS SCHS | (1) -12AN WATER PUMP ADAPTER |
| (4) 3/8-16 X 1 1/4" STAINLESS SCHS | PASSENGER SIDE |
| (4) GASKETS, SBC | (1) -12AN WATER PUMP ADAPTER |
| | DRIVER SIDE |

INSTALLATION

This remote -12AN Adapter Kit is made for our customers utilizing a remote water pump and an auxiliary radiator fan. The adapters are designed to fit in the stock water pump port location on the engine. Included in this kit are (2) sets of fasteners and (1) extra gasket set. One set of fasteners is 3/8" longer for those using a front engine motor plate.

1. Disconnect and remove the terminal from the negative battery terminal post.
2. Drain the fluid from the cooling system.
3. Remove the existing water pump.
4. Check and clean any old sealing material that may prevent the gaskets from sealing on the block.

NOTE: Lubricate the screw threads with oil prior to installation.

5. Coat both sides of the supplied gaskets with a high quality gasket sealer to prevent leaks.
6. Install the new fasteners and torque to 11 ft-lbs and final torque to 20 ft-lbs.
7. Plumb the Remote Water Pump to the radiator and engine block with -12AN fittings (not included).
8. Refill the coolant system and service the coolant system per manufacturers service manual.
9. Re-connect the negative battery terminal to its post.

Thank you for purchasing Moroso Performance Products

*For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am - 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906