



PART#65961
CARBURETOR AIR PAN KIT SINGLE 4500 CARB

PARTS LIST

- 2 ALUMINUM PANS**
- 1 4500 CARB FLANGE**
- 12 1/8" X 1/2" POP RIVETS**
- 1 FLAME RETARDANT FOAM 1 1/2" X 4" X 60"**

INSTALLATION

TO INSTALL AIR PAN: First measure opening in scoop adding 3" to the front to rear dimension for the foam seal. Drill 1/8" and pop rivet the two pan halves together at this dimension. Install carb flange on carburetor and lay the riveted pan on top. Place hood and scoop on car, centering pan in scoop opening. Remove hood and scoop and mark flange location on pan. Cut out an 8" diameter hole, centrally placed to the flange location. Using supplied rivets, drill and mount carb flange to pan. Lay the foam strip inside the outer lip and measure the length needed. Cut the foam to length and glue to pan assembly with weather stripping cement.

***For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time***

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906