



**WHEEL RIM SCREWS
P/N 90100**

INSTALLATION INSTRUCTIONS

PARTS: 35 – Wheel Rim Screws

1. Mark and center punch eight locations evenly spaced around the outer flange of the rim so the screws will penetrate into the tire bead.
2. Drill the holes using a 13/64" drill bit. Leave enough room to the edge of the rim to accommodate a 3/8" socket.
3. Deburr the holes, then mount and inflate tires to 25 psi.
4. Use a 3/8" socket to install the screws through the rim and into the tire bead.
5. Inflate/Deflate tire to normal operating pressure.

NOTE: When installing the screws into the rim just snug them up. Over tightening will result in snapping the head off the screw.

REV. B

121712

90100INST

***For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time***

MOROSO PERFORMANCE PRODUCTS, INC

80 CARTER DR • GUILFORD, CT 06437

Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com