



INSTALLATION INSTRUCTIONS

P/N: C2031

MAGNUM SERIES DIAGONAL LINK

This Diagonal Link is designed to work with the Competition Engineering Magnum Series 4-Link (P/N: C2028). When properly installed, this link will keep the rear axle housing centered in the chassis and eliminate excessive side-to-side movement. By eliminating this movement you allow the vehicle to track straight without excessive driver correction. PROPER INSTALLATION REQUIRES GTAW (TIG) WELDING OF ALL COMPONENTS!

PARTS LIST

- | | |
|-------------------------------|-------------------------|
| 1) Tube End – LH | 1) Tube End – RH |
| 1) 4130 Link Tube 36" | 2) 5/8" Link Bracket |
| 1) 1/2" LH Rod End | 1) 1/2" RH Rod End |
| 2) 1/2"-20 x 2-1/4" GR 8 Bolt | 2) 1/2"-20 Locknut |
| 1) 1/2"-20 Jam Nut - RH | 1) 1/2"-20 Jam Nut – LH |

INSTALLATION

1. Install the rear axle housing into the vehicle and square it up under the chassis. It is important to have the housing at ride height.
2. Loosen and remove the 5/8" front bolt of the lower bar on the driver's side. Slide the bolt through the supplied mounting bracket and replace the bolt back into its hole in the 4-link. Do not tighten the bolt at this time. Repeat this same procedure for the passenger side rear mounting bolt. Both brackets should be facing towards the inside of the car with the 1/2" holes facing up.
3. Thread the supplied jam nuts onto the 1/2" rod ends leaving approximately five threads showing between the jam nut and the eye of the rod end. Thread the rod ends into the tube ends.
4. Place the rod end assemblies into the mounting brackets and install the 1/2"-20 bolts. Do not install the locknuts at this time.
5. With the rear housing square in the chassis, slide the 36" link tube over one of the tube ends so that it seats against the shoulder on the tube end.
6. Raise the other end of the link tube, aligning it with the opposite tube end. Scribe a line onto the tube where it lines up with the shoulder on the tube end. This is your cut-off mark.
7. Cut the tube to length and deburr it.
8. Mock up the assembly in place and check for proper fit.
9. With the link tube removed from the vehicle, drill a 3/8" hole through each end of it approximately 1/2" from each end. This hole will be used to plug weld the tube end to the link tube.

*For Technical Assistance, call Competition Engineering's Tech Line at
(203) 458-0542, 8:30am-5:00pm Eastern Time*

COMPETITION ENGINEERING

80 Carter Drive • P.O. Box 1470 • Guilford, CT 06437
Phone: (203) 453-5200 • Fax: (203) 453-6906

Visit Us At www.competitionengineering.com

10. Remove the rod ends from the tube ends. Install the tube ends into the link tube and weld complete including the plug welds. Allow cooling sufficiently before installing.
11. Mount the welded assembly into the link brackets using the supplied 1/2" hardware. Check to see if the housing is square in the chassis. Adjust as necessary. Tighten all jam nuts.

**C2031INST
REV A
(050900)**

