



Plasma Pulse Capacitive Discharge Coil

P/N 72381

INSTALLATION INSTRUCTIONS

When installing a new Plasma Pulse Coil, it is recommended that new spiral core spark plug wires, new distributor cap and rotor, and new spark plugs are also installed to realize the full potential energy of the coil.

1. Disconnect negative battery cable.
2. Locate an area away from excessive heat and secure the coil to the mounting surface.

IMPORTANT NOTE: AFTER MOUNTING THE COIL, THE HOUSING OF THE COIL NEEDS TO BE GROUNDED WITH A CABLE OR STRAP TO A KNOWN GROUNDING SURFACE. THIS IS TO PREVENT DANGEROUS ELECTRICAL SHOCK. SCRAPE AWAY THE COATING ON THE COIL HOUSING WHERE YOU ARE ATTACHING THE GROUND WIRE.

3. Connect Coil Positive from the ignition box to the Positive lead of the coil. The positive lead from the pigtail connector is the single Red wire with Green Stripe.
4. Next, attach the Coil's Negative lead to the ignition box marked Coil Negative. The negative lead from the coil is Green with a Yellow Stripe. There are two negative leads in the pigtail connector, one of these can be cut off or terminated.
5. Connect an ignition coil wire from the coil to the distributor and reconnect the negative battery terminal.

***For Technical Assistance, call Moroso's Tech Line at
(203) 458-0542, 8:30am-5:00pm Eastern Time***

MOROSO PERFORMANCE PRODUCTS
80 Carter Drive • P.O. Box 1470 • Guilford, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com