



INSTALLATION INSTRUCTIONS

P/N:C9105 & C9205

FABRICATED AXLE HOUSING BRACE

To combat flex, Competition Engineering has designed the Fabricated Axle Housing Brace. This two-piece brace welds directly to the back of the Competition Engineering fabricated rear housing (P/N's: C9100 & C9200), triangulating the main housing with the axle tubes to eliminate any flex. By eliminating the flex, you increase the amount of power going to the tires and improve your ET's.

PARTS LIST

1) Driver's Side Brace

1) Passenger Side Brace

INSTALLATION

1. Trial fit the braces to the housing. If necessary trim the edges to fit using an angle grinder and a file.
2. Grind the area that the braces will be welded to ensure good penetration.
3. Tack weld the part to the housing in several places before beginning final welding.
4. In order to limit the amount of distortion, do not weld in one continuous bead. Instead weld in one-inch increments alternating from side to side.
5. For maximum effectiveness the brace should be welded on all areas that contact the housing.
6. We highly recommend that you use an alignment bar to prevent the tubes from distorting during the weld process.

C9205INST
REV A
(082400)

*For Technical Assistance, call Competition Engineering's Tech Line at
(203) 458-0542, 8:30am-5:00pm Eastern Time*

COMPETITION ENGINEERING

*80 Carter Drive • P.O. Box 1470 • Gullford, CT 06437
Phone: (203) 453-5200 • Fax: (203) 453-6906*

Visit Us At www.competitionengineering.com