

INSTALLATION INSTRUCTIONS

TUBULAR DRIVESHAFT SAFETY LOOP/KIT P/N: C3030

This kit is designed to offer a lightweight, weld-in alternative to the bolt-on driveshaft safety loop. It can also be used as a universal mount for various applications.

PARTS LIST

- (1) Mandrel-formed Loop
- (2) Loop Mounting Stubs
- (2) Snap Pins

INSTALLATION:

Rev. D 122012

- 1. Determine the proper mounting location for the Loop in a Driveshaft Safety Loop application where there is an existing crossmember. We recommend placing it a maximum of 6" from the universal joint in place.
- 2. Hold the hoop in place and mark the legs for trimming. Keep in mind that you will need 2-1/2" of clearance at the top of the hoop to allow its removal from the mounting stubs.
- 3. Trim the legs of the hoop to length.
- 4. Slide the mounting stubs into the ends of the hoop. Place the hoop in position on the crossmember and tack the stub ends to the crossmember. Remove the hoop and finish the weld.
- 5. Re-install the hoop and drill through the hoop legs and stubs using an 11/32" drill bit.
- 6. Install the supplied 5/16" bolts and locknuts, using a washer on each side of the hoop.

For Technical Assistance, call Competition Engineering's Tech Line at (203) 458-0542, 8:30am-5:00pm Eastern Time

COMPETITION ENGINEERING

80 Carter Drive • Guilford, CT 06437

Phone: (203) 453-5200 • Fax: (203) 453-6906

C3030INST